

# OEL Recommended Spare Parts List

C8600



Revision 18

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Special	Del/ Add	Remarks for environment
						per 500	per 1000	per 2000				
	Printer-NIP-PX736	1	43455902	PWR unit-ACDC Switch	1	1	2	4	230V OEL/ODA_230V/CHN/AOS/KOR			-
	Printer-NIP-PX736	2	43031601	PWR unit-DCDC	1	2	4	8	JPN/OEL/ODA_120V/ODA_230V/ AOS/CHN/TWN/KOR			-
	Printer-NIP-PX736	2	43694601	PWR unit-DCDC	1	2	4	8	C8650dn/JPN/OEL/ODA_120V/ ODA_230V			-
	Printer-NIP-PX736	3	43696801	OR-PVX	1	2	4	8	JPN/OEL/ODA_120V/ODA_230V/ AOS/CHN/TWN/KOR			-
	Printer-NIP-PX736	4	43363003	SP2 Maintenance Spec.	1	2	4	8	OEL			-
17	Printer-NIP-PX736	5	2381003P0101	FFC12-60-1.0-001	1	1	2	4				
	Printer-NIP-PX736	6	43412101	LED Head Unit-53MXG	4	2	4	8	JPN OEL (Old LED head)			-
	Printer-NIP-PX736	6	43686801	LED Head Unit-53STA	4	2	4	8	All distination 1)FW: v00.00.32 2) (43412101)			-
	Printer-NIP-PX736	7	43241301	Motor-DC-ID	1	1	2	4				-
	Printer-NIP-PX736	8	43446501	Motor-Fan (80)	1	1	2	4				-
	Printer-NIP-PX736	9	43191302	Motor-Fan (60) PowL	1	1	2	4				-
	Printer-NIP-PX736	10	43508301	Holder Assy.-Switch	1	2	4	8				-
	Printer-NIP-PX736	11	43446601	Plate-Assy.-Shield	1	2	4	8				-
	Printer-NIP-PX736	12	43170401	Plate-Shield-CU	1	2	4	8				-
	Printer-NIP-PX736	13	43270201	Cover-Assy.-Side (R)	1	2	4	8				-
	Printer-NIP-PX736	14	43276501	Cover-Side (L)	1	2	4	8				-
	Printer-NIP-PX736	15	43182601	Cover Assy.-Rear	1	2	4	8	OEL/ODA_120V/ODA_230V/ AOS/CHN/TWN/KOR			-
	Printer-NIP-PX736	16	43184303	Frame Assy.-OP (Panel)	1	2	4	8	OEL/AOS/CHN/TWN/KOR			-
	Printer-NIP-PX736	21	43310001	Duct-POW	1	1	2	4				-
	Printer-NIP-PX736	22	43310201	Insulator-POW	1	1	2	4				-
	Printer-NIP-PX736	23	43444101	Plate-Name	1	1	2	4	JPN/OEL/AOS/CHN/TWN/KOR ODA_120V/ODA_230V			-
	Printer-NIP-PX736	89	43178206	Cassette-Assy.	1	1	2	4	OEL			-
	Printer-NIP-PX736	119	43427203	Sheet-OP (Panel)	1	1	2	4	OEL/AOS/ODA_120V/ODA_230V			-
	Printer-NIP-PX736	120	43618501	Spring-Head	7	1	2	4				-
	Printer-NIP-PX736	121	43637101	Spring-Head	1	1	2	4				-
	Printer-NIP-PX736	122	42920808	Screw (SW+2W)	2	1	2	4				-
	Cover Assy.-OP (Panel)	17	43426301	Cover-OP (Panel)	1	2	4	8				-
	Cover Assy.-OP (Panel)	18	42068202	Button-Key	1	1	2	4				-
	Cover Assy.-OP (Panel)	19	43132502	OR-PRP	1	1	2	4	OEL/AOS/CHN/TWN/KOR			-
	Frame-Assy	20	43313601	Cover-Gear	1	1	2	4				-
	Frame-Assy	47	2381003P0083	TW-VF/SMCD13-740-1.0	1	2	4	8				-
	Frame-Assy	48	2381003P0084	TW-VF/SMCD21-230-1.0	1	2	4	8				-
	Frame-Assy	51	43240401	Plate-Side-L-Assy	1	1	2	4				-
	Frame-Assy	52	43241201	Plate-Side-R-Assy	1	1	2	4				-
	Frame-Assy	54	43245501	Frame-Assy-Hopping	1	2	4	8				-
	Frame-Assy	55	43246101	Gear-Holder-Assy	1	2	4	8				-
	Frame-Assy	56	43246401	Sensor-Assy-Fuser	1	1	2	4				-
	Frame-Assy	57	43246601	Frame-Assy-Contact	1	2	4	8				-
	Frame-Assy	58	43246801	Sensor-Assy-Regist	1	2	4	8				-

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Special	Del/ Add	Remarks for enviro nment
						per 500	per 1000	per 2000				
	Frame-Assy	65	43247501	Fuse-Cut-Assy	1	1	2	4				-
	Frame-Assy	66	43247701	Beam-Fuser-Assy	1	1	2	4				-
	Frame-Assy	67	43248001	Regist-Roller-Assy	1	2	4	8				-
	Frame-Assy	68	43250501	Guide-Eject-Assy- Lower	1	2	4	8				-
	Frame-Assy	72	42058304	Solenoid	1	2	4	8				G
	Frame-Assy	73	42058401	Spring-Solenoid	1	1	2	4				-
	Frame-Assy	74	43252401	Motor-Z18 (Spur)	2	2	4	8				-
	Frame-Assy	75	43251801	Gear-Reduction-L-Up	1	1	2	4				-
	Frame-Assy	76	43253501	Gear-Reduction-L-Up2	1	1	2	4				-
	Frame-Assy	77	43313101	Gear-Reduction-L-Up3	1	1	2	4				-
	Frame-Assy	78	43361001	Gear-Reduction-L-Up4	1	1	2	4				-
	Printer-Unit (PX736)	29	43438901	OR-P6Y	1	2	4	8				-
	Printer-Unit (PX736)	30	43183601	Guide-Eject-Assy- Upper	1	2	4	8				-
	Printer-Unit (PX736)	33	43410503	Cover-Assy-Top	1	1	2	4	OEL/CHN/ODA_120V/ODA_2 30V			-
	Printer-Unit (PX736)	36	43179301	MPT-Assy	1	2	4	8				-
	Printer-Unit (PX736)	40	43311901	Spring-Torsion (L)	1	1	2	4				-
	Printer-Unit (PX736)	41	43312001	Spring-Torsion (R)	1	1	2	4				-
	Printer-Unit (PX736)	42	43359801	CONN Cord-AMP8P- AMP4P, AMP4P	1	2	4	8				-
	Printer-Unit (PX736)	43	43405001	CONN Cord-AMP11P- AMP11P	1	2	4	8				-
	Printer-Unit (PX736)	44	43360501	CONN Cord-AMP6P- AMP3P, AMP3P	1	2	4	8				-
	Printer-Unit (PX736)	46	43409601	CONN Cord-JST8P-AMP2P	1	2	4	8				-
	Guide-Eject-Assy- Upper	31	43183801	Shaft Assy. -Eject (FU)	1	1	2	4				-
	Guide-Eject-Assy- Upper	32	43184001	Shaft Assy. -Eject (FD)	1	1	2	4				-
	Cover-Assy-Top	34	43311701	Cable-Assy. -Head	1	2	4	8				-
	Cover-Assy-Top	35	43224701	Cover-Top	1	1	2	4				-
	Cover-Assy-Top	35	43381801	Cover-Top-Sub	1	1	2	4				-
	Cover-Assy-Top	35	42293101	Spring-Torsion (Sub)	1	1	2	4				-
15	Cover-Assy-Top	108	43793601	OR-Motor-FAN (40)	1	1	2	4				
	Cover-Assy-Top	109	43590701	Duct-Fan-FU	1	1	2	4				-
	Holder-Pickup-Assy	37	43417901	Roller-Assy. -Pickup	1	3	6	12				-
16	Cover-Front Assy.	38	43411001	Roller-Feed (OW)	1	3	6	12		Included in consumable item 107		-
	Cover-Front Assy.	39	43418001	Frame-Assy. -Separator	1	3	6	12				-
	Printer-Unit (PX736 PDL)	49	43629001	CONN-Regist- Cord (R_bend)	1	2	4	8				-
	Printer-Unit (PX736 PDL)	50	43628901	CONN-Regist- Cord (L_bend)	1	1	2	4				-
	Plate-Side-R-Assy	53	43242201	Guide-Side-R-Assy	1	1	2	4				-
	Plate-Side-R-Assy	110	43242701	Motor-Assy-Fuser	1	1	2	4				-
	Plate-Side-R-Assy	112	43314401	Motor-Assy. -Belt	1	1	2	4				-
	Plate-Side-R-Assy	118	43245401	Rack-Lift-Up-R	1	1	2	4				-
12	Plate-Side-R-Assy	139	43825901	Gear-Idle-Fuser	1	1	2	4				
14	Plate-Side-R-Assy	143	43893801	Gear-Reduction-A	1	1	2	4				
14	Plate-Side-R-Assy	144	43314101	Plate-Main2-Assy	1	1	2	4				
12	Plate-Side-R-Assy	140	43158101	CONN Cord-JST4P-JST4P	1	1	2	4				

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Special	Del/ Add	Remarks for environment
						per 500	per 1000	per 2000				
12	Plate-Side-R-Assy	141	4PB4083-6198P001	WAVE WASHER A	2	1	2	4				
	Sensor-Assy-Fuser-A	59	43601701	Lever-Sensor-FUIN-Assy	1	1	2	4				-
	Sensor-Assy-Fuser-A	60	43334501	Spring-Torsion	1	1	2	4				-
	Sensor-Assy-Regist	61	43247201	Shutter-Assy	1	1	2	4				-
	Sensor-Assy-Regist	62	42755801	DC-Solenoid	1	2	4	8				-
	Sensor-Assy-Regist	63	43132302	OR-PRC	2	2	4	8				-
	Sensor-Assy-Regist	64	5654200P0001	GP2TC2J0000F	1	2	4	8				G
	Guide-Eject-Assy-Lower	69	42063301	Lever-Eject-Sensor	1	2	4	8				-
	Guide-Eject-Assy-Lower	70	40386501	Spring-SNS (F/R)	1	2	4	8				-
	Guide-Eject-Assy-Lower	71	40135301	Photo-Interrupter	1	2	4	8				G
16	Cassette-Assy	90	42088801	Frame-Separation-Assy.	1	3	6	12		Included in consumable item 106		-
16	Cassette-Assy	116	42089001	Spring-Separation	1	1	2	4		Included in consumable item 106		-
	Cassette-Assy	123	43178701	Spring-Plate	2	1	2	4				
13	Cassette-Assy	142	43436506	Cover-Assy-Cassette	1	1	2	4	OEL			
16	Consumable	106	43651503	Rollerset-Tray1	1	1	2	4	OEL	Includes cassette assy items 90 & 116 & Frame assy hopping item 115		-
16	Consumable	107	43651803	RollerSet-MPT	1	1	2	4	OEL	Includes cover front item 38		-
	Motor-Assy-Fuser	111	43242801	Motor-DC-FU	1	1	2	4				-
	Motor-Assy. -Belt	113	43242601	Motor-Z15 (Helical)	1	1	2	4				-
16	Frame-Assy-Hopping	115	43334901	Roller Assy. -Hopping	1	3	6	12		Included in Consumable item 106		-
	Plate-Side-L-Assy	117	43241001	Rack-Lift-Up-L	1	1	2	4				-